
























SURFACE PREP & POLISHED CONCRETE

Application	Method	STI Diamond System & Item Numbers										
Surface Prep	Dry	#00 Prep Tool (for rough profile)	One set of double PCD EG Prep Tools consists of 50% left-hand tools and 50% right-hand tools.					#00L (left) 571603412		#00R (right) 571603418		
		#0 Prep Tool (for smooth profile)	#0S (soft bond) 540242000		#0 (standard) 540243000		#0H (hard bond) 571522325					
Polished Concrete	Dry	 EGT Diamond System (GREEN)	 EGT#1 540574001	OR	 EGT#1S (soft-bond) 541402000	 EGT#2 540578002	 EGT#3 540591503	 EGT#4 540760004	 EGT#5 540800005	 EGT#6 540800006	 EGT#7 540800007	 EGT#8 540800008
	Wet-Dry	 CLC Diamond System (RED)	DRY		WET STEPS				DRY STEPS			
		 CLC#1 530400001	 CLC#2 530700002	 CLC#3 530746003	 CLC#4 530752004	 CLC#5 530860005	 CLC#6 530870006	 CLC#7 530880007				

Number of Diamonds per Step Needed for a Specific P/M Machine

STI-2807 & 2818LP	STI-2420 & 2418LP	STI-3030 & 3038LP	STI-4430 & 4438LP
6	12	12	24



Service • Support • Success