




January 2016

SURFACE PREP & TERRAZZO POLISHING

Application	Method	STI Diamond System & Item Numbers						
Surface Prep	Dry	#00 Prep Tool (for rough profile)	One set of double PCD EG Prep Tools consists of 50% left-hand tools and 50% right-hand tools.		#00L (left) 571603412		#00R (right) 571603418	
		#0 Prep Tool (for smooth profile)	#0S (soft bond) 540242000		#0 (standard) 540243000		#0H (hard bond) 571522325	
Polished Terrazzo	Dry-Wet	 TPS Diamond System (ORANGE)	DRY STEPS		WET STEPS			
			 TPS#1S 640900001	 TPS#2 640900002	 TPS#3 640900003	 TPS#3.5 Grout Pans 640900035	 TPS#4 640900004	 TPS#5 640900005

Number of Diamonds per Step Needed for a Specific P/M Machine			
STI-2807 & 2818LP	STI-2420 & 2418LP	STI-3030 & 3038LP	STI-4430 & 4438LP
6	12	12	24



Service • Support • Success